C-Reality Film Scanner



Cintel International Ltd
Watton Road
WARE
Herts
SG12 0AE
England
al: +44 (0) 1920 463939
x: +44 (0) 1920 460803

tel: +44 (0) 1920 463939 fax: +44 (0) 1920 460803 e-mail: <u>sales@cintel.co.uk</u> web: www.cinteltelecine.com



User Handbook

Issue 1

While every effort has been made to ensure that the contents of this document are accurate Cintel International equipment is under constant review to bring about improvements in design, and a unit may differ in detail from that described.

© Cintel International Ltd 2004

The copyright of this document is the property of Cintel International Ltd. and the document contains proprietary information of Cintel International Ltd. It is supplied in confidence and must not be used for any purpose other than that for which it is supplied. No part of the document shall be reproduced, published or disclosed to a third party without the prior written consent of Cintel International Ltd.

Chapter 1 - Introduction

CONTENTS

Introduction Control About This Handbook Other Handbooks Cintel Other Manufacturers Options

Introduction

Your C-REALITY Telecine (shown in Figure 1) is a multi-resolution film scanning system that employs the very latest imaging technology. It provides images of uncompromised quality, while maintaining the versatility that you would expect from a Cintel telecine.

C-REALITY incorporates Standard Definition, 2K Data and C-VIP, (C)olour (V)ector (I)mage (P)rocessing

C-VIP is a powerful built-in colour processing system that provides colour correction at 14-bit resolution regardless of system standard.

Control

Although designed to be operated from a remote control desk C-REALITY can also be controlled and configured from the Local Control Panel where much of the desk's functionality is replicated. C-REALITY supports control desks from the following manufacturers:

- Da Vinci
- Pandora.
- Tangent

Please contact manufacturers for specific details.

About This Handbook

This handbook, C-REALITY - User Handbook, is Volume 1 and is intended for the user and operator and provides:

- a specification (Chapter 2),
- a simplified functional description (Chapter 3) and
- user operating details (Chapter 4).

Other Handbooks

<u>Cintel</u>

Cintel can supply engineering procedure manuals following completion of a Cintel training course. Contact Cintel for further information.

A Python II supplement is supplied with machines integrated with 2K and 4K data capture.

Other Manufacturers

This telecine can be controlled by other manufacturers' remote control systems. For these operating details and/or details of any other equipment or option fitted to your telecine please refer to the relevant manufacturer's documentation.

Issue 1 Page 1 of 2

OptionsThe following four major options can be added to the C-REALITY telecine:

Oliver 4K Data

Grace HSDL

Audio HD

DSX Update (Oliver/HD/HSDL/4K)



Figure 1 – C-REALITY Telecine

Issue 1 Page 2 of 2

Chapter 2 Specification

Contents

Environment Film Transport and Servo System Film Scanning System CVIP (Colour Vector Image Processor) Digital I/O Audio System¹ Supplies Dimensions and Weight

Cintel policy is one of continuous improvement, and the right is reserved to change specifications at any time without notice.

Environment

Performance will be within the specified limits when the telecine is operated in an ambient temperature between 16°C and 25°C and in a dust-free atmosphere.

Recommended operating temperature range: 18 to 25°C.

Film Transport and Servo System

Gates

2K resolution S35/35mm and S16/16mm interchangeable film gates. Gate apertures designed to encompass maximum camera shooting apertures.

Film Drive

Capstan driven directly by servo-controlled motor. Feed and take-up spooling servos individually controlled to provide constant film tension.

Standards/Systems

Video, Standard Definition CCIR 601, CCIR 656 (4:4:4 or 4:2:2 SDI) 625 lines, 50Hz, 2:1 interlace 525 lines, 59.94Hz, 2:1 interlace.

¹ If fitted

Chapter 2 Specification

(Optional) Video, High Definition

1080i 59.94/60/50 HD Serial Digital, Y.Cr,Cb (SMPTE 292M, 22:11:11), 10 bit

1080i 59.94/60/50 HD Serial Digital, (22:22:22) RGB and Y,Cr,Cb (SMPTE 292M)10 bit

Switching between HD and other standards is less than 15 seconds

Data, High Resolution

2K data (2048 x 1536) or (2048 x 1556) (Optional) 4K data (4096 x 3112)

Film Frame Rate

Standard Definition

525, 5-30fps - Precise control of speed in 0.01fps (frames per second) increments. 525, 40-50fps and *(60fps with fpf option)*

625, 5-30fps - Precise control of speed in 0.01fps increments 625, 33-50fps.

(Optional) High Definition

HD Interlace Formats 5-30fps HD Progressive formats 24/25fps

2K Data

Still-frame, 6fps HSDL 15fps

(Optional) 4K Data

Still-frame, 0.3 fps

Film Capacity

Core mounted film up to 2,000 feet (approx. 18 inches diameter). Adapters for film spools.

Issue 1 Page 2 of 7

Fast Running (shuttle)

Continuously variable shuttle in forward and reverse modes with coherent images.

Maximum speed:

10 x normal.

Inching

Single step, forward and reverse.

Stop Mode

Rapid, precise stopping with full specification quality still-frame 'active stop' picture display.

Picture Stability

Better than ±0.05% of film frame height between 5fps and 30fps.

Film Framing (perforation nudge, 35mm only)

Adjustment of framing by ±1/4 frames (35mm).

Adjustment of framing by $\pm \frac{1}{2}$ frames (16mm).

Film Scanning System

Film Gates

All gates fitted with manual focus control.

Light Source

Thick face plate, seven inch, high-intensity cathode ray tube de-mountable from CRT assembly. CRT assembly incorporates pre-aligned deflection coils and integral magnetic screen.

Negligible x-ray radiation.

Pick-up Devices

Red, green and blue high-resolution solid state sensors.

Digital Scan Control (applicable to 625/525 and 2K. And Optional, 4K and HD)

Provides film scanning for:

X, Y Pan and Zoom (area magnification x 0.8 to x 4, limited to x 2 in 2K and optional 4K) Anamorphic unsqueeze (2:1)

Rotate.

Issue 1 Page 3 of 7

Scan Effects (applicable to 625/525 and 2K. And Optional 4K and HD)

Scan effects include:

Scan aspects of 4:3 and 16:9 Linear/non-linear X-Y squeeze.

Digital Blanking Control

Output Blanking (not applicable to 2K or Optional 4K).

X, Y, size, position and zoom range 0 to 100% of video image.

Appropriate for 4:3 and 16:9 operation.

Beam Current

Switchable:

OFF (CRT switched OFF)

Low 150µA

Normal 300µA.

Tube Saver Mode. (Sets CRT to 150uA and defocusses the scan raster.)

Geometry and Linearity

Any point in the picture is within 0.25% of picture height relative to its true position. Any errors are distributed evenly.

Shading (automatic)

Overall

Less than 1% of signal level with gamma of 0.4 over film density range of 0.0 to 3.3.

Differential

Less than 1% of signal level at gamma of 0.4 over film density range of 0.0 to 3.3.

CRT Correction (automatic)

Includes burn and grain correction, compensates for 3:1 reduction of light output at 300µA.

Resolution without aperture correction

625/525

Not more than 2dB down at 400 lines in the picture centre.

Corner resolution within 1dB of centre resolution at 300 lines. Does not take film losses into account.

(De-rate by 1dB for S16mm).

2K and optional /HD/4K

Not more than 3dB down at 800 lines in the picture centre. Corner resolution within 2dB of centre resolution at 600 lines. Does not take film losses into account.

Issue 1 Page 4 of 7

CVIP (Colour Vector Image Processor)

Digital Channel

Full RGB Primary and multi-vector Secondary correction.

Variable saturation 0 to 200%.

Enhancement (digital)

Individually adjustable red, green and blue aperture correction.

0 to +12dB maximum horizontal and vertical.

0 to -12dB negative enhancement (softening) included.

Signal-to-Noise Ratios (at gamma 0.4)

Measured with N.D. 1 in the vision gate, the ratio being 700mV divided by r.m.s. noise voltage.

625/525

Red: Better than 55dB. Green: Better than 60dB. Blue: Better than 55dB.

Optional HD

Red: Better than 50dB. Green: Better than 50dB. Blue: Better than 50dB.

2K

Red: Better than 55dB. Green: Better than 55dB. Blue: Better than 55dB.

Optional 4K Data

To be advised

<u>Masking</u>

Choice of pre-set masking equations for several film stocks and user programmable masking equations for special work.

Pre-set masking for Kodak film materials are:

Colour Print

Vision & Primetime negative Inter positive (5244 & 7244).

Issue 1 Page 5 of 7

C-Reality
User Handbook

Chapter 2 Specification

Digital I/0

SD

Inputs

CCIR 601/656 Serial links 4:4:4 or 4:2:2 external reference.

Mixed sync 2V to 4V or composite video, negative going.

Output

CCIR 601/656 Serial links 4:4:4 or 4:2:2 (Clean and reference wipe outputs).

Optional HD

Inputs

Tri-Level sync

Output

SMPTE -292M Serial link 22:22:22 or 22:11:11 aka "4:4:4" or "4:2:2"

<u>Data</u>

2K/Optional 4K LVDS multi-pin connection for coupling to Cintel Python II (With HD option only) 2K only HSDL via HD "4:4:4" serial outputs

Optional Audio System²

Audio Sources

35mm COMOPT Dolby A & SR stereo, 16mm COMOPT.

External stereo inputs. Internal tone generator.

Frequency Response

Optical 16mm: 50Hz to 7kHz, ±2dB. Optical 35mm: 50Hz to 8kHz, ±2dB.

Signal-to-Noise UNweighted

Optical

Better than 55dB.

Audio Delay

0 to 1.3 seconds.

Issue 1

² If fitted

Supplies

Local Supply	Current Rating
194-257V, 50Hz	20A
97-129V, 50/60Hz	40A

Dimensions and Weight Width: 1620mm Height: Depth: Weight: 1790mm 905mm 850Kg (net).

Page 7 of 7 Issue 1

Chapter 3 - General Description

CONTENTS

Introduction
Film Transport System
Film Scanning System
Scanning Effects
Signal Conditioning System
Colour Processing System
Audio System
Audio Monitoring
Control
Local Controls

IN-TEXT ILLUSTRATIONS

Top Level Block Diagram	Figure 1	
Film Transport System Block Diagram	Figure 2	
Film Scanning System Block Diagram	Figure 3	
Signal Conditioning System Block Diagram	Figure 4	
Colour Processing Block Diagram	Figure 5	
Audio System Block Diagram	Figure 6	
Control Block Diagram	Figure 7	

Introduction

C-REALITY is a multi-standard telecine and data scanner that combines the advantages of digital flying-spot scanning techniques with the very latest technology, to produce images of uncompromised quality regardless of the selected operating standard.

The telecine is available in a number of configurations to support 525, 625 and high definition television standards plus true 2K and 4K data output.

The telecine can be divided into five major functional systems as shown in Figure 1.

(See Oliver and Grace Supplements for full description of these optional features)

Issue 1 Page 1 of 9




Figure 1 – Top Level Block Diagram

Issue 1 Page 2 of 9

The Film Transport System precisely controls film position. Information derived from the film by the Film Scanning System is converted into electrical signals. These signals are subsequently digitised and conditioned by the Signal Conditioning System and then processed by the Colour Processing System. The Colour Processing System provides picture output to the selected standard. The film soundtrack is picked up by the Audio System¹ to provide the audio output.

Although designed to be operated from a remote control desk C-REALITY can also be controlled and configured locally where much of the desk's functionality is replicated.

Film Transport System

The Film Transport System is digitally controlled and achieves near-pin registration stability without the need for mechanical pin registration. It transfers film at a constant rate on a series of guide rollers from the feed core, through the vision gate, past the audio head (if fitted) and onto the take-up core. See Figure 2. The film is scanned by a raster from the CRT as it moves across the vision gate.




Figure 2 - Film Transport System Block Diagram

¹ Option Issue 1

All transport mechanism components are mounted on the deck plate located behind the film transport door. This door and the lower motorised door are safety-interlocked to force the telecine into a STOP condition when either of these doors is opened.

A servo-controlled sprocket-free capstan drive ensures that film velocity is constant and film handling is gentle. Capstan stability is maintained by feedback of velocity information from an optical tachometer encoder on the capstan shaft.

A capstan phasing loop ensures correct picture framing by comparing pulses from the sprocket-driven encoder with station syncs. If framing is incorrect an error signal is produced; this signal is used to modify the capstan velocity to restore correct framing. When the transport is stopped the film is positioned in the vision gate to give a correctly framed picture. In this 'active stop' condition the capstan and spooling servos are enabled but stationary.

The film feed and take-up cores are individually driven by separate servo-controlled D.C. motors. This reduces the effect of load variations on the capstan by maintaining the correct film tension. The speeds of the spooling motors are controlled by signals generated by encoders on compliance arms located on either side of the vision gate. In the absence of film the encoder outputs inhibit transport operation. A or B winds are automatically sensed.

The film transport system provides film motion in both forward or reverse directions in 0.01fps increments up to 30fps (525, SD), 30fps (HD option) and various speeds in data mode to a maximum of 6fps or (15fps with HSDL option in 2K) and 0.3fps in 4K option. Film can be shuttled in forward and reverse directions at up to 10 x normal speed in all modes of operation. The mechanism accommodates 16/S16mm and 35/S35mm film formats (1, 2, 3 perforation and 4 perforation) with simple substitution of the vision gate to change from 16/S16² to 35/S35. Normal, wide screen and anamorphic film is accepted.

Film cores are driven through rubber pads and conversion from one gauge to another requires only the addition or removal of spacers. Film run tension is adjustable to accommodate valuable archive material. PTR (Particle Transfer Rollers) rollers are included as standard on the deck plate for film cleaning purposes. The PTRs are optional in the film lacing path.

Film Scanning System (See Oliver Supplement for description of optional Oliver feature)

The Film Scanning System scans the moving film as it passes through the vision gate. The modulated light produced by the different film image densities is then separated into its red, green and blue constituent colours. The light is then converted into electrical signals by (A)valanche (P)hoto (D)iodes. The system consists of a digitally scanned high quality thick faceplate CRT and a simple optical arrangement with colour splitters and filters as shown in Figure 3. Using this system image resolution is only limited by the optical path and the CRT spot size.

Light from the raster produced by the CRT is focused onto the film by an objective lens. A condenser lens behind the film then collects the transmitted light. Using a series of dichroic mirrors and filters, the red, green and blue components are separated and converted into electrical signals by three separate APD's.

While these APD's are used to create the image three additional devices, the reference APD's, are used to form an active compensation system. This system monitors the CRT face and generates signals that are used to remove all shading and fixed-pattern phosphor irregularities. Light is carried by fibre optic cables from the CRT face to the reference detectors. This system coupled together with a straight light path provides excellent signal to noise ratios and pure colorimetry at all resolutions.

The mirrors, filters and APD's are housed in an enclosed cell box to eliminate the effects of external light interference; the interchangeable condenser lenses fitted onto the gate and towards the rear of Oliver are also shielded from interference by light traps. The gate light trap is user removable to assist in film lacing.

² The 16mm and 35mm gates have adjustable format masks to cover the sound track area on 16 and 35mm material. Issue 1

Scanning Effects

All scanning effects are "optical"; that is, all effects are achieved by manipulating the scan. This avoids the resolution limitations experienced when processing a digital representation of the image.

Scanning effects include zoom, rotation, linear and non-linear X-Y squeeze as well as many other more advanced effects. Provision is made for reproducing wide-screen or anamorphic film at any desired film and/or TV aspect ratio. Refer to the relevant control system literature for further information.




Figure 3 - Film Scanning System Block Diagram

Signal Conditioning System

The Signal Conditioning System accepts the modulated red, green, signals from the image APD's, converts the signals to digital and applies correction in readiness for colour processing as shown in Figure 4.




Figure 4 – Signal Conditioning System Block Diagram

Light falling on all six APD's produces current signals that are converted into voltage signals by the head amplifiers. Afterglow correction is then applied before being converted into 14-bit digital signals by A to D converters.

Issue 1 Page 6 of 9

The digitised signals generated from the reference APD's are used to apply *pixel conditioning* to the signals produced from the image APD's. Shading correction, burn correction, grain removal and blemish correction is all applied before the three separate red, green and blue colour channel signals are subjected to colour processing.

Colour Processing System

The Colour Processing System accepts the colour channel outputs from the Signal Conditioning System and outputs pictures to the selected standard and configuration. See Figure 5.




Figure 5 – Colour Processing System Block Diagram

The incoming colour channel signals are passed to the input store and then onto the primary colour corrector. If configured for optional High Definition operation, the input store splits the incoming signal into three separate signals representing the upper, middle and lower thirds of the image for delivery to three separate colour channels.

The primary colour corrector applies lift, gamma and gain adjustments by means of look-up tables and also applies signal inversion for negative film.

The colour vector image processor performs hue, saturation and luminance operations on the signals before being passed to the aperture corrector. The output from the aperture corrector feeds the anti-aliaser and then the output store.

Issue 1 Page 7 of 9

The output store uses three framestores to provide the interlacing necessary for 525/625 operation and 3:2 field sequencing. It also recombines the segmented colour channel signals on optional High Definition configured machines.

The signal from the output store feeds into the output stages. The SD output stages contain a reference frame that takes its input either from the output store or from an external digital input. This frame can be combined with the current output to provide a comparison of picture quality and content. The signals from the output stage/s are available at the termination panels on the rear of the machine.

Audio System³ (Optional)

The Audio System picks up the film soundtrack and amplifies it to provide the audio output. See Figure 6. The system is able to introduce a delay of up to 1.3 seconds into the output and accommodates 16mm optical, and 35mm optical mono and stereo sound.




Figure 6 - Audio System Block Diagram

Audio signals from the selected source, an optical sound head reader or an external input, are passed through a Dolby noise reducer and then filtered accordingly to limit the bandwidth. The signals are then digitised, subjected to a user definable digital delay of up to 1.3 seconds, converted back to analogue and adjusted for gain before being distributed to output and monitoring amplifiers.

³ Audio capability is an option Issue 1

Chapter 3
General Description

The digital delay is incorporated to compensate for the relative positions of the vision gate and audio reader. It also allows for delays introduced by downstream processing on the video path.

An internally generated test tone (1kHz) is provided to test the audio path.

Audio Monitoring

Audio signals are monitored by the loudspeaker situated in the upper control panel and level is adjusted with the adjacent control. When stereo is selected left and right channels are combined to produce a single monaural drive. Audio can also be monitored from the rear of the machine on Termination Panel 2. These outputs can be configured for left/right or sum & diff. monitoring.

Control

C-REALITY is designed to be operated remotely from a remote control desk that provides full control over all facilities. The desk, essential for full telecine operation, communicates with the telecine through an Ethernet connection. A limited amount of control is however provided at the telecine. Refer to manufacturer's literature for separate control desk operation.

Local Controls

Local controls are generally located on one of two control panels on the front of the machine and allow the operator to lace film and perform all basic machine functions.

Details of all local controls and the most common operating procedures can be found in Chapter 4.




Figure 7 Control System Block Diagram

Issue 1 Page 9 of 9

Chapter 4 - Operating Information

Contents	Gate Code Reader Automatic (Figure 18)
General	Gate Code Reader HD S35mm (Figure 19)
Storage	Engineering Password (Figure 20)
Handling of Film Material	Matrix Menu Oliver (Figure 21) If Option Fitted
Time-Limited Trial Software	Matrix Menu Grace Gains (Figure 22) If Option Fitted
Control Reference	Matrix Menu Grace Detail (Figure 23) If Option Fitted
Power ON/OFF Switch	Lifetime Options (Figure 24)
Defaults after Initialisation	Time Limited Options (Figure 25)
Lower Sliding Door Switch (DOOR)	Expired Options (Figure 26)
Lower Control Panel	Video Standard SD (Figure 27)
STOP	Video Standard HD (Figure 28) If Option Fitted
RUN/SHUTTLE FORWARD	Data Standard (Figure 29)
RUN/SHUTTLE REVERSE	Select Standard confirmation (Figure 30)
35mm NUDGE	Video Setup (Figure 31)
FRAME UP/DOWN	Scan Effects Menu showing H Linear Keystone (Figure 32)
JOG/SHUTTLE WHEEL	Scan Effects Menu showing V Linear Keystone (Figure 33)
Upper Control Panel	Scan Effects Menu showing Focus Effects (Figure 34)
Dedicated Controls	Scan Effects Menu showing Rotate (Figure 35)
VAC	Scan Effects Menu showing X Y Zoom (Figure 36)
PEC	Engineering Menu #2 (Figure 37)
CRT ON	APC Control Menu (Figure 38)
LOCAL	Test Pattern Menu (Figure 39)
Loudspeaker Volume	PCC Test Pattern menu (Figure 40)
Display Overview	Pixcon Test Pattern Menu (Figure 41)
Screen-Saver	Lute (Breakout) Test Pattern Menu (Figure 42) If Option Fitted
Menu Navigation and Functionality	Debug File Filter Menu (Figure 43)
Menu Hierarchy (Figure 6)	Debug running list example (Figure 44)
Top Level Menu Pre Gamma (Figure 7)	Debug Task Menu (Figure 45)
Top Level Menu Post Gamma (Figure 8)	Log Mask Menu (Showing Film selected) (Figure 46)
PEC Levels (Figure 9)	Log Mask (None) (Figure 47)
Status and Shutdown Pages (Figure 10)	Log Mask (User) (Figure 48)
Audio Menu (Figure 11) If Option Fitted	CVIP Menu (Figure 49)
Pan / Zoom (Figure 12)	CVIP Vector Select (Figure 50)
Auto Alignment Menu (Figure 13)	CVIP Vector Highlight Menu (Figure 51)
Perform Shading (Figure 14)	PCC Differential Menu (Post Lift Gamma shown) (Figure 52)
Perform Detector Calibration (Figure 15)	PCC Differential Menu (S Gamma shown) (Figure 53)
Time Code Reset (Figure 16)	PCC Differential Menu (Knee) (Figure 54)
Engineering Menu #1 (Figure 17)	PCC Differential Menu (Highlight shown) (Figure 55)
8 ··· 8 ··-········ (8····· -·)	PCC Differential Menu (Lowlight shown) (Figure 56)
	Anti Alias Control (Figure 57)

Issue 1 Page 1 of 137

Engineering Menu #3 (Figure 58)	Mono/Differential Video Ref vs Ref (Figure 85)	
Transport Configuration Menu (Figure 59)	Mono/Differential Video Colour Ref (Figure 86)	
Output Blanking Menu (Figure 60)	Scan Alignment Amplitude (Figure 87)	
Reference Store (External shown) (Figure 61)	Scan Alignment Astig (Figure 88)	
Reference Store (Reference shown (Figure 62)	Scan Alignment Coils (Figure 89)	
Manual Shading Menu (Figure 63)	Scan Alignment Dynamic Focus (Figure 90)	
Data Output LUT Selection Menu (Figure 64) If Option Fitted	Scan Alignment Preset Fly back (Figure 91)	
Data Output LUT File Load (Figure 65) If Option Fitted	Scan Alignment Offset (Figure 92)	
Data Output LUT File Delete (Figure 66) If Option Fitted	Scan Alignment Pincushion (Figure 93)	
Data Output Normal Mode (Figure 67)	Scan Alignment Skew (Figure 94)	
Data Output Light Log Mode (Figure 68)	Scan Alignment Static Focus (Figure 95)	
Data Output Light Monitor Mode (Figure 69)		
Data Output Prescale Log Mode (Figure 70)	General Information	
Data Output Prescale Monitor Mode (Figure 71)	Deck Plate	
Engineering Menu #4 (Figure 72)	Controls	
Real-Time Clock (Figure 73)	Film Tension Push-button	
Front End Setup Menu (Figure 74)	Loop Guide Thumbscrew	
Front End Setup Blanking (Figure 75)	Door Safety Interlock System	
PEC Setup Main Signal (Figure 76)	Gate	
PEC Setup Reference Signal (Figure 77)	Gate Features	
Archive Menu (Figure 78)	Focus Knob and Lock	
Archive Load (Figure 79)	Aperture Ring	
Archive Save (Figure 80)	Edge Guidance Lever/s	
Mono/Differential Video Normal (Figure 81)	Latch able Pressure Plate Actuating Arm	
Mono/Differential Video Main vs Main (Figure 82)	Brake Pedal	
Mono/Differential Video Colour Main (Figure 83)		
Mono/Differential Video Main vs Ref (Figure 84)		

Operating Procedures

Powering-Up Telecine	Procedure 1
Daily Cleaning and Telecine Warm-Up	Procedure 2
Selecting and Fitting a Vision Gate	Procedure 3
Lacing Film Rolls	Procedure 4
Lacing Film Loops	Procedure 5
Detector Calibration and Auto Alignment	Procedure 6
Running Film	Procedure 7
Powering-Down	Procedure 8
Invoking a Test Pattern	Procedure 9
Installing System Software (for the first time)	Procedure 10
Setting the Best Primary Colour Correction at the Local Control Panel	Procedure 11
Setting Remote Controller Base memories and Defaults	Procedure 12
Other Functionality	Procedure 13

Issue 1 Page 2 of 137



Electrical supplies in excess of 50 (fifty) volts are potentially hazardous or lethal; supplies of up to 30kV exist within the C-REALITY Telecine. THE TELECINE MUST ONLY BE OPERATED WITH ALL COVERS IN PLACE; covers and access doors that are secured with key operated locks must only be removed by qualified service personnel for maintenance purposes.

The Telecine is designed so that it CANNOT be operated with either the film transport or lower sliding doors open; safety interlock switches force the Telecine into a STOP condition when either of these doors are opened. Do NOT in any way over-ride, modify or alter the operation of these switches; these switches are fitted for safety purposes and can only be over-ridden by a qualified engineer equipped with the correct service tool.



Ensure that film tension is switched OFF (film tension push-button extinguished) BEFORE touching any part of the film transport mechanism.

GENERAL

Although designed to be operated from a remote control desk C-REALITY can also be controlled and configured from the Local Control Panel where much of the desk's functionality is replicated.

This chapter discusses C-REALITY functionality only; remote control desk operation (through an Ethernet link) is NOT discussed. Refer to the relevant manufacturer's documentation for control desk details.

This chapter is divided into two parts:

A reference section. This section explains the function of the controls at the Telecine and illustrates the menus available on the hierarchical control system that is accessible from the local control panel. Some options and settings NOT covered by the procedures' section are explained in this section. Other options are covered by separate supplements.



The hierarchical menu control system offers access to some functionality that is intended for engineering purposes only.

A procedures' section. This section guides the user step-by-step through the most common operations. (ii)

Storage

When not in use C-REALITY should be left with both doors CLOSED. This helps to prevent dust and similar small particles from contaminating the deck plate area. Film should NOT be left laced when not in use as doing so may cause permanent film distortion.

Handling of Film Material

It is recommended that normal in-house procedures for handling original film material be observed.

Time-Limited Trial Software

This Telecine is configured in the factory to function with the software options purchased at the time of sale. These options are documented in a licence file on the configuration disk that contains:

- a description of each fitted option,
- a Key (or encrypted ASCII string) that permits use of the option and
- an indication of the duration of the option (or key).

Options fitted to your Telecine (and expired options) are displayed on the Telecine Options Menu.

Page 2 of 137 Issue 1

Key Duration and Usage

There are three key types:

Lifetime Key

Options purchased at the time of sale are normally enabled for use with a lifetime key.

7-Day. Time-Limited Trial Key

This key is designed to enable Cintel engineers to temporarily restore full functionality to the Telecine following a service call. This key will then be replaced by an appropriate key issued directly by Cintel. A 7-day key can only be issued once for any given option.

28-Day. Time-Limited Trial Key

This key is designed to enable the use of an option that is in the process of being purchased. When purchased this key will then be replaced by a lifetime key issued directly by Cintel.

56-Day. Time –Limited Trial Key

This key is designed to enable the use of an option that is in the process of being purchased. When purchased this key will then be replaced by a lifetime key issued directly by Cintel.

366-Day. Main Software Key. This key is issued annually and is supplied based on the terms of the license issued at the time of purchase.

Issue 1 Page 3 of 137

CONTROL REFERENCE

This reference section explains the functions of the controls available at the Telecine. Controls are located on the upper and lower control panels and on the deck plate as shown in Figure 96.



Figure 1 Location of Controls

Issue 1 Page 4 of 137

Power ON/OFF Switch



4 Warning

The power ON/OFF switch on the Telecine does NOT switch power ON/OFF to the remote control desk. Refer to relevant manufacturer's documentation for details.

The power ON/OFF switch is located at the front of the machine on the lower left-hand side. Move the switch up into the position to switch power ON, move the switch down into the O position to switch power OFF. Ensure that the Telecine is shutdown correctly (as described in Procedure 8) BEFORE the power is switched OFF.



Failure to observe the correct shutdown procedure may corrupt the internal hard drive.

C-REALITY recognizes an incorrect shutdown sequence, and at next power up will, on the local display panel, advise there had been an incorrect shutdown sequence. The C-REALITY will then automatically check and automatically "rebuild" the hard disk contents

Defaults After Initialisation

When switched ON and following initialisation the following defaults apply:

- CRT heaters OFF, CRT available.
- EHT is OFF.
- Local control is selected; *LOCAL* LED is illuminated.
- Display shows Top Level Menu.
- PEC and shading boards are NOT aligned.
- Film tension is OFF.
- Mechanism is in Stop condition.
- Film standard is determined by vision gate selection.
- Film format determined by setting at previous power-down.
- Film Type will revert to Negative
- Aperture correction is turned OFF.
- Audio output is OFF (if option is fitted).
- Some functions available via local display menu system adopt default settings.

Lower Sliding Door Switch (DOOR)



Press DOOR to open/close the lower sliding (adjacent) door. If desired the door can be operated manually with the handle. This door gives access to the CRT location and the CRT face filter drawers and mount adaptors. The door also gives access for the adjustment of gate aperture, gate focus. The door will open automatically if the film transport door is opened.

Note: Your Telecine can be configured so that the door will not automatically close if the film transport door is closed. Refer to Cintel Customer Support department for details.

Note: The sliding door switch will be disabled by the safety interlock system if a Stop command has NOT been issued. If the door switch fails to operate first press STOP.

Issue 1 Page 5 of 137

Lower Control Panel

The Lower Control Panel, located just below and to the right of the Film Transport Door, provides the Telecine's film transport controls as shown in Figure 2.




Figure 2 Lower Control Panel



Press STOP to instantly stop film motion in either direction and at any speed. This control remains available under remote control.



Press RUN/SHUTTLE FORWARD to initiate film movement from the feed core to the take-up core as follows:

- Press once to transport film at selected run forward frame rate.
- Press twice to transport film at selected shuttle forward frame rate. Maximum shuttle speed equates to 250 frames per second (fps) for 35mm and 500fps for 16mm.

Run forward and shuttle forward frame rates are pre-determined either at the remote control desk (see manufacturer's documentation) or at the local control panel (see Transport Configuration Menu).

Auto-Stop

Auto-Stop protects film from winding off the core by automatically stopping the film transport system when either end of the film is approaching. This feature is selected from the Transport Configuration Menu.

Issue 1 Page 6 of 137



Press RUN/SHUTTLE REVERSE to initiate film movement from the take-up core to the feed core. This control operates in a similar manner to RUN/SHUTTLE FORWARD.



Press 35mm NUDGE to frame the Telecine picture by nudging the film (in the forward direction) in one perforation (or ¼ frame for 4 perf material) increments. This ensures that the film can be correctly framed (to ¼ frame accuracy with 4 perf material) without having to re-position the film on the sprocket. Operates in 35mm mode only. (Nudges 3 perf material 1/3 frame, 2 perf material ½ frame)





Press FRAME UP or FRAME DOWN to accurately frame the Telecine picture when film is in motion. To frame the picture when in Stop set the user framing default from the Transport Configuration Menu.



Press and/or rotate the JOG/SHUTTLE WHEEL as follows:

To Select Operating Mode. Press to select the Jog or Shuttle mode. The currently selected mode is shown on the upper control panel display Top Level Menu.

When in Shuttle Mode.

- Press to stop film transport (if running) and select Jog mode.
- Rotate to vary shuttle speed in small steps up to the maximum in either direction.

When in Jog Mode.

- Press to select Shuttle mode.
- Rotate to move one frame at a time in either direction.

Issue 1 Page 7 of 137

Upper Control Panel

The Upper Control Panel (shown in Figure 3) located to the right-hand side of the Film Transport Door provides access to many local control facilities primarily through the use of a hierarchical menu control system. The menus are displayed on an Electroluminescent (EL) display and are navigated/selected with the adjacent *soft* controls. The panel also includes a number of dedicated controls. Behind this control panel are located the CDROM and floppy disk drives for System Software and Firmware respectively.




Figure 3 Upper Control Panel

Dedicated Controls



Press VAC to apply aperture correction to the colour channel output. The amount of correction is set by the adjacent digipot. The LED is illuminated when this mode is selected.

The VAC control is only available when the display menu is at the TOP level



Press PEC to display the PEC Control Menu (see Figure 9) on the adjacent display and allocate control of signal detector PEC levels to the three digipots (identified in Figure 5. This control is disabled when PEC level adjustment is inappropriate, for example, when the Auto Alignment Menu is selected. The adjacent LED is illuminated when this mode is selected.

Note: The PEC control gives easy access to the PEC Control Menu that is embedded within the hierarchical menu control system.

Issue 1 Page 8 of 137



Press CRT ON to initiate the CRT heater warm-up period. This takes approximately 30 seconds. The CRT heater must be on and warmed-up before EHT becomes available. If the CRT is switched off when the EHT is on, the EHT is automatically switched off. The warm-up sequence is illustrated in Figure 4. This control remains available under remote control.

Note: The CRT heater is subjected to a timeout and will switch off automatically if the EHT is off for more than 30 minutes.




Figure 4 CRT Heater Warm-up/EHT Availability Sequence



Press LOCAL to select either local control at the Telecine or remote control from the remote control desk. The adjacent LED indicates the current selection:

- LED illuminated local control.
- LED extinguished remote control.

Pressing LOCAL will change the availability status of functions on the Telecine; when remote control is selected all functions with the exception of CRT ON and STOP are no longer available.

Loudspeaker Volume¹

Determines the audio monitoring volume level of the adjacent loudspeaker.

Issue 1 Page 9 of 137

¹ If audio option fitted

Display Overview

The typical layout of the display is shown in Figure 5




Figure 5 Typical Display Layout

Two rows of push-buttons, one located above the display (a to 2) and one below (f) to 1) provide access to further menus and functions. Four digipots (1) to 4) allow for adjustment of parameters as indicated on the display.

Screen-Saver

Following a period of approximately ten minutes of local control panel inactivity the display screen-saver will be activated and the soft push-buttons disabled. All other local controls remain available. On the next button press (or rotation of a digipot) the screen-saver will be switched off and the soft push-buttons re-enabled. This set-up determines that functions available on the soft push-buttons are only accessible when the screen-saver is OFF.

Note: The screen-saver displays the machine serial number and customer name, alternative screen saver text can be set in the CONFIG.TXT file. Refer to Cintel Customer Support department for details.

Issue 1 Page 10 of 137

Menu Navigation and Functionality

The menus are navigated with the soft push-buttons. By default the Top Level Menu is displayed. From this menu all other menus can be accessed. The menu hierarchy is shown in Figure 6 and the further menus are shown in Figures 7 to 95, these figures summarise the functionality provided by the menus.




Figure 6 Menu Hierarchy

Some of the menus below are interactive. Right click over the buttons with red circles to move around the menus. Buttons without red circles have a single function or their function is cyclical selection, in which case the button has the cyclic list marked adjacent to it.

Issue 1 Page 11 of 137




Figure 7 Top Level Menu (Pre Gamma)

Issue 1 Page 12 of 137




Figure 8 Top Level Menu (Post Gamma)

Issue 1 Page 13 of 137




Fig 9 PEC Levels

Issue 1 Page 14 of 137




Figure 10 Status and Shutdown Pages

Page 15 of 137 Issue 1




Fig 11 Audio Menu

Issue 1 Page 16 of 137




Figure 12 X Y Zoom

Issue 1 Page 17 of 137




Fig 13 Auto Align Menu

Issue 1 Page 18 of 137




Fig 14 Perform Auto Align Status

Issue 1 Page 19 of 137



Fig 15 Perform Detector Calibration Status

Issue 1 Page 20 of 137

C-Reality User Handbook




Fig 16 Time Code Reset Confirm

Issue 1 Page 21 of 137




Fig 17 Engineering # 1 Menu

Issue 1 Page 22 of 137

C-Reality User Handbook




Fig 18 Gate Code Menu Showing Automatic Selection

Issue 1 Page 23 of 137




Fig 19 Gate Code Menu Showing Manual Selection

Issue 1 Page 24 of 137




Fig 20 Engineering Enable Anti Alias Control

Issue 1 Page 25 of 137




Fig 21 Matrix Menu, Oliver Setup

Issue 1 Page 26 of 137




Fig 22 Matrix Menu, Grace Gains Setup

Issue 1 Page 27 of 137




Fig 23 Matrix Menu, Grace Detail Setup

Issue 1 Page 28 of 137

C-Reality
User Handbook Operating Information




Fig 24 Lifetime Options

Page 29 of 137 Issue 1




Fig 25 Time Limited Options

Issue 1 Page 30 of 137




Fig 26 Expired Options

Issue 1 Page 31 of 137




Fig 27 SD Video Standards Menu

Issue 1 Page 32 of 137




Fig 28 HD Video Standards Menu

Issue 1 Page 33 of 137




Fig 29 DATA Standards Menu

Issue 1 Page 34 of 137




Fig 30 Standards Confirmation

Issue 1 Page 35 of 137




Fig 31 Video Setup Menu

Issue 1 Page 36 of 137




Fig 32 Scan Effects Menu Showing H Linear Keystone

Issue 1 Page 37 of 137




Fig 33 Scan Effects Menu Showing V Linear Skew

Issue 1 Page 38 of 137




Fig 34 Scan Effects Menu Showing Focus Effects

Issue 1 Page 39 of 137




Fig 35 Scan Effects Menu Showing Rotate

Issue 1 Page 40 of 137




Fig 36 Scan Effects Menu Showing X Y Zoom

Issue 1 Page 41 of 137




Fig 37 Engineering #2 Menu

Issue 1 Page 42 of 137




Fig 38 Aperture Correction Menu

Issue 1 Page 43 of 137




Fig 39 Test Pattern Menu

Issue 1 Page 44 of 137




Fig 40 PCC Test Pattern Menu

Issue 1 Page 45 of 137




Fig 41 Pixcon Test Pattern Menu

Issue 1 Page 46 of 137




Fig 42 Breakout Test Pattern Menu

Issue 1 Page 47 of 137




Fig 43 Debug File Filter Menu

Issue 1 Page 48 of 137




Fig 44 Debug Running Example

Issue 1 Page 49 of 137




Fig 45 Debug Task Menu

Issue 1 Page 50 of 137




Fig 46 Log Mask Menu

Issue 1 Page 51 of 137




Fig 47 Log Mask (None)

Issue 1 Page 52 of 137




Fig 48 Log Mask User

Issue 1 Page 53 of 137




Fig 49 CVIP Menu

Issue 1 Page 54 of 137




Fig 50 CVIP Vector Select

Issue 1 Page 55 of 137




Fig 51 CVIP Vector Highlight Menu

Issue 1 Page 56 of 137




Fig 52 Differential PCC Menu

Issue 1 Page 57 of 137




Fig 53 Differential PCC S Gamma

Issue 1 Page 58 of 137




Fig 54 Differential PCC Knee

Issue 1 Page 59 of 137




Fig 55 Differential PCC Highlight

Issue 1 Page 60 of 137




Fig 56 Differential PCC Lowlight

Issue 1 Page 61 of 137




Fig 57 Anti Alias Control

Issue 1 Page 62 of 137




Fig 58 Engineering #3 Menu

Issue 1 Page 63 of 137




Fig 59 Transport Configuration menu

Issue 1 Page 64 of 137




Fig 60 Output Blanking Menu

Issue 1 Page 65 of 137




Fig 61 Reference Store External shown

Issue 1 Page 66 of 137




Fig 62 Reference Store Reference Shown

Issue 1 Page 67 of 137




Fig 63 Manual Shading Menu

Issue 1 Page 68 of 137




Fig 64 Data Output LUT Selection Menu

Issue 1 Page 69 of 137



Fig 65 Data Output LUT File Load confirmation

Issue 1 Page 70 of 137




Fig 66 Data Output LUT File Delete confirmation

Issue 1 Page 71 of 137




Fig 67 Data Output normal Mode

Issue 1 Page 72 of 137




Fig 68 Data Output Light (Log Mode)

Issue 1 Page 73 of 137




Fig 69 Data Output Light (Monitor Mode)

Issue 1 Page 74 of 137




Fig 70 Data Output Prescale (Log Mode)

Issue 1 Page 75 of 137




Fig 71 Data Output Prescale (Monitor Mode)

Issue 1 Page 76 of 137




Fig 72 Engineering #4 Menu

Issue 1 Page 77 of 137




Fig 73 Real Time Clock Setup

Issue 1 Page 78 of 137




Fig 74 Front End Setup Menu

Issue 1 Page 79 of 137




Fig 75 Front End Setup Blanking

Issue 1 Page 80 of 137




Fig 76 PEC Setup Main Signal

Issue 1 Page 81 of 137




Fig 77 PEC Setup Reference Signal

Issue 1 Page 82 of 137




Fig 78 Archive Menu

Issue 1 Page 83 of 137




Fig 79 Archive Load

Issue 1 Page 84 of 137




Fig 80 Archive Save

Issue 1 Page 85 of 137




Fig 81 Mono / Differential Video Normal

Issue 1 Page 86 of 137




Fig 82 Mono / Differential Video Main vs Main

Issue 1 Page 87 of 137



Fig 83 Mono / Differential Video Colour Main

Issue 1 Page 88 of 137




Fig 84 Mono / Differential Video Main vs Ref

Issue 1 Page 89 of 137




Fig 85 Mono / Differential Video Ref vs Ref

Issue 1 Page 90 of 137




Fig 86 Mono / Differential Video Colour Ref

Issue 1 Page 91 of 137




Fig 87 Scan Align Amplitude

Issue 1 Page 92 of 137




Fig 88 Scan Align Astig

Issue 1 Page 93 of 137




Fig 89 Scan Align Coils

Issue 1 Page 94 of 137




Fig 90 Scan Align Dynamic Focus

Issue 1 Page 95 of 137




Fig 91 Scan Align Preset Fly back

Issue 1 Page 96 of 137




Fig 92 Scan Align Offset

Issue 1 Page 97 of 137




Fig 93 Scan Align Pincushion

Issue 1 Page 98 of 137




Fig 94 Scan Align Skew

Issue 1 Page 99 of 137




Fig 95 Scan Align Static Focus

Issue 1 Page 100 of 137

Deck Plate

The Deck Plate (shown in Figure 96) provides controls that are associated with film lacing and are only accessible when the film transport door is open.




Figure 96 Deck Plate Controls

Issue 1 Page 101 of 137



Ensure that film tension is switched OFF (film tension push-button extinguished) BEFORE touching any part of the film transport mechanism.

Controls



Film Tension Push-button

Press the *Film Tension Push-button* to apply (or remove) tension to the film by applying (or removing) power to the spooling and compliance arm motors. The lamp in this push-button indicates the following status and actions. See Table I.




Table I Indications Given By Film Tension Push-button Lamp

Off Tension OFF – the compliance arms are in the film lacing/unlacing position, film (if laced) is NOT tensioned. This position must be selected before lacing or unlacing film.

...with brakes ON. The spooling brakes are normally ON when tension is OFF to protect from film spillage if film is laced.

...with brakes OFF. If the brake pedal is pressed the brakes will be released. Although the backplates can now be rotated manually the spooling motors driving them each offer gentle resistance to lacing. This aids film loading as it not only reduces slack in the film when laced, but also deters the user from winding the end of the film onto the destination backplate in the wrong direction when lacing.




Figure 97 Compliance Arms – Lacing/Unlacing Position

Issue 1 Page 102 of 137



Taking-up/Releasing Tension - tension is either being taken-up or released.

<u>Taking up tension.</u> The compliance arms rotate in a controlled manner into the film run position to apply film tension, the spooling brakes are released and power is applied to the spooling motors (spooling mode only). This takes a few seconds. Film tension can be adjusted from the *Transport Configuration Menu*.



Figure 98 Compliance Arms – Film Run Position

Note: In the unlikely event that tension is unsuccessfully taken-up the servo system will return to the Tension OFF mode. To take-up tension again, first remove excess slack by releasing the brakes and rotating the backplates as necessary, then press the Film Tension Push-button again.

Note: The LHS compliance arm is NOT disabled when in loop mode and will rotate when taking-up film tension. This does NOT interfere with loop operation.

Releasing tension. The compliance arms rotate to release film tension, the spooling brakes are applied and power is removed from the spooling motors. This takes a few seconds.

On Tension ON (Spooling Mode) - power remains applied to the spooling motors and the spooling brakes are OFF. The compliance arms remain in the film run position so tension is applied. The film transport system is ready to accept commands (if the door is closed). This position must be selected before running film from core to core.

Flashing Tension ON (Loop Mode) - the spooling brakes are OFF and the compliance arms remain in the film run position so tension is applied. The film transport system is ready to accept commands (if the door is closed). This position must be selected before running a film loop.



Fault Condition – Refer to Cintel Customer Support department.

Loop Guide Thumbscrew

The Loop Guide (shown in Figure 99) enables film loops (normally used for test purposes) to be fitted onto the machine. This is located in the centre of the deck plate between the two backplates, as shown in Figure 96.

Issue 1 Page 103 of 137




Figure 99 Loop Guide

Film loops are laced round the guide roller that is adjusted to remove excess slack² in the film. The guide roller is adjusted and locked in position by means of the loop guide thumbscrew.

Door Safety Interlock System

The Telecine has a safety interlock system fitted to the two front doors. If one of these doors is opened when the Telecine is transporting film the servo system will shut down and the film transport controls will be disabled. If the offending door is then closed the transport controls are re-enabled but the servo system will NOT resume its previous operating mode.

Gate

The Telecine can accommodate both 35/S35 and 16/S16 gates (shown in Figures 100 and 101 respectively). Provision is made to store one gate behind the Upper Control Panel.




Figure 100 35mm/S35 Gate

Issue 1 Page 104 of 137

² A small amount of slack is required to allow the RHS compliance arm to operate effectively.




Figure 101 16mm/S16 Gate

Gate Features

Focus Knob and Lock

Both gates are fitted with a manual focus knob and focus lock. These are located on the top of the gate. Adjust the optical focus for optimum focusing as shown on a picture or waveform monitor. Lock the knob by rotating the lock towards the Stop.




Figure 102 Gate Focus Knob and Lock

Aperture Ring

Both gates have variable aperture lens. Aperture ring position is detected by a sensor built into the deck plate and can be monitored at the remote control desk (refer to relevant manufacturer's documentation for further details).

- The aperture on the 35mm gate should usually be set fully open. To ensure that the gate aperture is set fully open, rotate the aperture ring to the end of its travel so that the dot on the ring is at its lowest point as shown in Figure 100.
- The lens on the 16mm gate should usually be set to 2.5. To ensure that the gate aperture is set to this position, rotate the aperture ring so that the dot on the ring is adjacent to -2.5 as shown in Figure 101.

Issue 1 Page 105 of 137

Chapter 4
Operating Information

Edge Guidance Lever/s

Gates are fitted with edge guidance lever/s, one lever on the 35/S35mm gate (see Figure 100) and two on the 16/S16mm gate (see Figure 101). These are operated after film is laced through the gate to ensure the film is correctly seated on the skid plate.

Latchable Pressure Plate Actuating Arm

A latchable plate is fitted to each gate that is used to apply a pre-determined down-force to the film as it passes over the skid plate. This is intended to be used as a focusing aid for bowed stock as it helps to flatten the film. The plate is activated by the actuating arm shown in Figures 100 and 101.

Brake Pedal

The brake pedal is a foot-operated control used as an aid for film loading. If the pedal is pressed when film tension is OFF (the pedal is disabled when film is tensioned) the brakes will be released and the backplates will now be able to be rotated manually (albeit under the gentle resistance offered by the spooling motors – see *Film Tension Pushbutton*). Taking the foot off of the pedal re-applies the brakes. Note that the pedal must be released before applying film tension.

Issue 1 Page 106 of 137

OPERATING PROCEDURES

This section guides the user step-by-step through the most common operations. To assist navigation through the menus shown on the upper control panel display, the following notation is added at the end of an instruction to identify the path to a particular menu function:

ITOP LEVEL MENU #> "NEXT MENU NAME" #> "NEXT MENU NAME" #>1, etc, where

"##" - represents a soft-button identity,

">" - should be read as "calls up menu",

"NEXT MENU NAME" - represents a menu identity.

Options and settings NOT covered by these procedures are explained in the *Control Reference* section of this chapter.

1. Powering-Up



The power ON/OFF switch on the Telecine does NOT switch power ON/OFF to the remote control desk. Refer to relevant manufacturer's documentation for details.

- 1.1. Switch on Power move the power switch up into the position to switch power ON. The switch is located at the front of the machine on the lower left-hand side. The Telecine should NOT have film laced. The Telecine can be switched on either before or after the remote control desk. If the machine has not been shut down correctly a delay will be incurred, as data on the hard drive needs to be checked for possible corruption.
- 1.2. <u>Wait for Initialisation</u> Wait for approximately four minutes. During this period software will be downloaded from CD-ROM and Floppy Disk, C-REALITY will initialise and the display on the local control panel will show the *Debug Menu* (the Debug Menu is beyond the scope of this documentation and is NOT described in this handbook). **Do NOT attempt to perform any operations during initialisation**.
- 1.3. When this process is complete the display will show the *Top Level Menu*. The following defaults apply:

CRT heaters OFF, CRT available.

EHT is OFF.

Local control is selected; LOCAL LED adjacent is illuminated.

Display shows Top Level Menu.

PEC and shading boards are NOT aligned.

Film tension is OFF.

Mechanism is in Stop condition.

Film standard is determined by vision gate selection.

Film format always defaults to Negative.

Aperture correction is turned OFF.

Audio output is OFF (if option is fitted).

Functions available via local display menu system adopt default settings.

Issue 1 Page 107 of 137

1.4. Switch ON CRT Heater - Press CRT ON to switch on the CRT heater, the display will show EHT WAIT. When completed the display will show EHT READY, this takes approximately 30 seconds and indicates that EHT is now available. The CRT heater is subjected to a timeout and will switch off automatically if the EHT is off for more than 30 minutes



Do not leave Telecine in this mode (CRT heater switched ON, EHT switched OFF) as it could shorten CRT life. Either switch the EHT ON or the CRT heater OFF.

The warm-up sequence is illustrated below:




Fig 103

1.5. Switch on EHT - Press (Top Level Menu) to switch on the EHT supply. EHT will be switched on after a short delay of a few seconds; the display will show EHT ON. [TOP LEVEL MENU]. EHT can be switched on from menus other than the Top Level Menu (see Upper Control Panel/Menu Navigation and Functionality).

2. Daily Cleaning and Telecine Warm-Up

The Telecine should be cleaned daily before operating.

2.1. <u>Open Doors</u> – Open the film transport door. The lower door will open automatically.



Take care not to scratch the surfaces identified in Para. 2.2.

- 2.2. <u>Clean and Dust</u> During warm-up clean the capstan, rollers, spooling hub rubber pads and 16mm spacers with a lint-free cloth moistened with a mild detergent solution. Dust the CRT and the external optical surfaces of the vision gate with a camel-hair or similar brush.
- 2.3. <u>Allow Telecine to Finish Warm-Up</u> If possible allow a total warm-up period of at least 30 minutes.


Issue 1 Page 108 of 137

3. Selecting and Fitting a Vision Gate


Note: If The Oliver Option is fitted refer to the Oliver supplement as some of the fitting instructions differ from those below

The Telecine can accommodate both 35/S35 and 16/S16 gates. If the vision gate to be used has NOT been used before with this Telecine it is first necessary to align the CRT for use with the gate. Details for performing scan (CRT) alignment are available from Cintel service department and must only be carried out by qualified personnel. Provision is made to store one gate behind the Upper Control Panel.

- 3.1. Rotate the light flap away from the gate condenser lens area –to give access to the gate position.
- 3.2. <u>Select and Fit Gate</u> Fit selected gate onto telecine as follows:
 - (a) Pick-up gate using the handle provided ensuring that the focus knob is uppermost. The gate can be steadied with the other hand if desired.
- 3.3. (b) Locate top of gate A onto supporting rod B as shown in diagrams 1 and 2. The edge guides located either side of the rod determine an approximate left-right position.




- (c) Engage roller C under top of latch D. The bottom of the gate should locate firmly.
- (d) Lock gate in position by rotating the handle to the right. See Figure 3. The rear of the handle will now prevent the latch from moving.



A barcode on the rear of the gate identifies the gate type to the machine by means of a gate code. The current gate code is displayed on the Video Standard Menu.

Issue 1 Page 109 of 137

3.4. <u>Check Gate Aperture</u> – Ensure that the gate aperture is set correctly. The lens on the 35mm gate should usually be set fully open; the lens on the 16mm gate should usually be set to 2.5. To ensure that the gate is set correctly rotate the aperture ring to the relevant position as shown opposite. Ring position is detected by a sensor built into the deck plate and can be monitored at the remote control desk. Refer to relevant manufacturer's documentation for details.




- 3.5. Rotate the light flap to sit between the gate and the cell box
- 3.6. <u>Cancel Scan Effects and Offsets</u> Cancel (reset) any scan effects or offsets (if active). This can be done locally or at the remote control desk. Refer to relevant manufacturer's documentation for details.

4 Lacing Film Rolls



Ensure that film tension is switched OFF (film tension push-button extinguished) BEFORE touching any part of the film transport mechanism.

- 4.1 <u>Check Film Drive is OFF</u> Ensure that film tension is switched OFF (film tension push-button extinguished). With tension OFF the compliance arms are in the film lacing/unlacing position and the spooling brakes are normally ON (unless released by the action of the brake) to protect from film spillage if film is laced.
- 4.2 Set Film Type Press (Top Level Menu) to cycle through the options available on the display, NEG (Negative), POS (Positive) and IP (Inter-Positive). [TOP LEVEL MENU (2)].
- 4.3 <u>Remove Feed Core Holder</u> Remove the feed core holder from the spindle by pressing and holding the release lever and then pulling the holder off.




Issue 1 Page 110 of 137

- 4.4 <u>Check Backplate Rubber Spacer</u> For 16mm and S16mm only, ensure that the extra rubber spacer behind the backplate IS fitted; this is NOT required for 35mm or S35mm rolls.
 - (a) To remove the spacer, remove the backplate from the spindle by pulling the backplate forwards, remove the spacer from the spindle and then re-fit the backplate.
 - (b) To fit the spacer, remove the backplate from the spindle by pulling the backplate forwards, fit the spacer ensuring that the side with the written caution faces towards the deckplate and then re-fit the backplate. See figure.
- 4.5 <u>Fit Feed Roll</u> Fit the feed roll onto the backplate spindle. The table below shows the recommended emulsion and soundtrack orientations for each film type.

Material	Emulsion	Sound Track
35 Neg/IP	Towards gate	Towards deck plate
35 Pos	Away from gate	Towards deck plate
16 Neg/IP	Towards gate	Away from deck plate
16 Pos	Away from gate	Away from deck plate

- 4.6 Ensure the core locates fully onto the backplate drive key.
- 4.7 <u>Fit Core Holder</u> Fit the core holder onto the spindle so that for 35mm and S35mm the SMALL boss faces towards the backplate, and for 16mm and S16mm rolls the LARGE boss faces towards the backplate. Ensure the core holder and release lever are both correctly located after fitting.




Issue 1 Page 111 of 137



Always lace film leader where possible as exposed film can be scratched by handling.

- 4.9 <u>Release Spooling Brakes</u> Press and hold down the brake foot-pedal to release the spooling brakes. Although the backplates can now be rotated manually the spooling motors driving them each offer gentle resistance
- 4.10 <u>Lace Film</u> Taking hold of the end of the roll, lace the film according to the markings on the deck plate and attach to the take-up core. To lace through the gate first hinge back the light trap from the condenser lens area and then release the gate pressure plate to give access to the skid plate. Engage the pressure plate and replace the light trap when laced. If desired film can be laced round the PTR rollers.



- 4.11 <u>Check Lacing</u> Ensure that the film is correctly located on the sprocket and the rollers, and that there is no slack in the film path, as shown opposite.
- 4.12 <u>Re-apply Brakes</u> Release the brake foot-pedal to re-apply the brakes.
- 4.13 Set Film Transport Mode Ensure that Loop Mode is set to OFF. Press (Engineering Menu #1) to toggle between ON and OFF. ITOP LEVEL MENU (F) > ENGINEERING MENU #1(d).




Ensure that the film is correctly located on the sprocket before applying film tension.

4.14 Restore Film Drive and Check Lacing – Press (Film Tension Push-button) to apply power to the motors and release the spooling brakes. The backplates move into position and the compliance arms rotate in a controlled manner into the film run position to apply film tension. This takes a few seconds. When complete the push-button will be illuminated. (If the film's A or B wind has changed since the previous lacing, the transport will make two attempts to tension. This is normal and part of the Auto A/B wind system)


Issue 1 Page 112 of 137



4.15 Note: In the unlikely event that tension is unsuccessfully taken-up the servo system will return to the Tension OFF mode. To re-take-up tension, first remove excess slack by releasing the brakes and rotating the backplates as necessary, then press (*Film Tension Push-button*) again.



- 4.16 Ensure Film is Correctly Seated on Skid Plate Operate edge guidance lever/s as shown opposite.
- 4.17 <u>Engage Pressure Plate (as required)</u> Latch plate in position. The plate applies a pre-determined down-force to the film as it passes over the skid plate. This is intended to be used as a focusing aid for bowed stock as it helps to flatten the film.
- 4.18 <u>Check Film Transport</u> Close the film transport door and press *DOOR* to close the lower door. Press *RUN/SHUTTLE FORWARD* once and allow the film to run for several seconds, then press *STOP* and open the doors. Check that the film lies correctly on all rollers, both compliance arms and the sprocket below the vision gate. Note: Your Telecine can be configured so that the lower door will close if the film transport door is closed. Refer to Cintel Customer Support department for details.
- 4.19 Re-check Film Seating Operate the edge guidance lever/s and then close the doors again.
- 4.20 <u>Adjust Gate Focus</u> Adjust the optical focus on the gate for optimum focusing as shown on a picture or waveform monitor. Rotate the focus lock lever to lock the focus.



Issue 1 Page 113 of 137

5 Lacing Film Loops




Ensure that film tension is switched OFF (film tension push-button extinguished) BEFORE touching any part of the film transport mechanism.

- 5.1 <u>Check Film Drive is OFF</u> Ensure that film tension is switched OFF (film tension push-button extinguished). With tension OFF the compliance arms are in the film lacing/unlacing position and the spooling brakes are normally ON (unless released by the action of the brake) to protect from film spillage if film is laced.
- 5.2 Set Film Type Press (Top Level Menu) to cycle through the options available on the display, NEG (Negative), POS (Positive) and IP (Inter-Positive). [TOP LEVEL MENU (2)].
- 5.3 <u>Lace Film Loop</u> Lace the film loop according to the markings on the deck plate lacing round the roller on the loop guide. The table opposite shows the recommended emulsion and soundtrack orientations for each film type.

Material	Emulsion	Sound Track
35 Neg/IP	Towards gate	Towards deck plate
35 Pos	Away from gate	Towards deck plate
16 Neg/IP	Towards gate	Away from deck plate
16 Pos	Away from gate	Away from deck plate

Using the thumbscrew secure the plate that supports the roller in a position that removes excess film slack but leaves a small amount for compliance arm operation. To lace through the gate first hinge back the light trap between the condenser lens and the rear of the gate, then slide the film between the skid plate and pressure plate. Replace the light trap once laced. Note that the left-hand side compliance arm is not used in this mode.



5.5 <u>Check Lacing</u> - Ensure that the film is correctly located on the sprocket and the rollers, and that there is no slack in the film path, as shown in the figure.

Issue 1 Page 114 of 137

5.6 Set Film Transport Mode – Ensure that Loop Mode is set to ON. Press (Engineering Menu #1) to toggle between ON and OFF. ITOP LEVEL MENU (F) > ENGINEERING MENU #1(a).




Ensure that the film is correctly located on the sprocket before applying film tension.

5.7 <u>Restore Film Drive and Check Lacing</u> – Press (*Film Tension Push-button*) to apply power to the compliance arm motors. The compliance arms rotate in a controlled manner into the film run position to apply film tension. This takes a few seconds. When complete the push-button will flash.




Note: In the unlikely event that tension is unsuccessfully taken-up (because of excess film slack) the servo system will return to the Tension OFF mode. To re-take-up tension, first remove excess slack and then press (*Film Tension Push-button*) again.



- 5.8 Ensure Film is Correctly Seated on Skid Plate Operate edge guidance lever/s as shown opposite.
- 5.9 <u>Engage Pressure Plate (as required)</u> Latch Pressure plate in position. The plate applies a pre-determined down-force to the film as it passes over the skid plate. This is intended to be used as a focusing aid for bowed stock as it helps to flatten the film.
- 5.10 <u>Check Film Transport</u> Close the film transport door and press *DOOR* to close the lower door. Press *RUN/SHUTTLE FORWARD* once and allow the film to run for several seconds, then press *STOP* and open the doors. Check that the film lies correctly on all rollers, the compliance arm and the vision gate sprocket. Note: Your Telecine can be configured so that the lower door will close if the film transport door is closed. Refer to Cintel Customer Support department for details.

Issue 1 Page 115 of 137

- 5.11 <u>Re-check Film Seating</u> Operate the edge guidance lever/s and then close the doors again.
- 5.12 Adjust Gate Focus Adjust the optical focus on the gate for optimum focusing as shown on a picture or waveform monitor. Rotate the focus lock lever to lock the focus.



<u>6</u> Automatic Alignment and Detector Calibration

During the alignment process the output of the video channel is frozen. Consequently the pictures observed on the picture monitor and any other external monitor are also frozen. Automatic alignment aligns the PEC and shading boards.



Ensure that film tension is switched OFF (film tension push-button extinguished) BEFORE touching any part of the film transport mechanism.



Avoidance of external illumination

The option Oliver is very sensitive to stray light and it is essential to avoid any external illumination, (daylight, artificial or from monitoring equipment) from falling on the film path when C-REALITY is in use or during detector calibration and auto align. It is generally sufficient to ensure the Oliver light shield is fitted and the lower deckplate door is closed.

6.1 Detector Calibration

Notes: When using a new gate for the first time and at other times when the local displays prompts, Detector Calibration will be required.

A detector calibration automatically includes an Auto Align, it is therefore not necessary to perform an Auto Align after a detector calibration

- 6.2 <u>Check Gate Focus</u> Ensure the gate is correctly focused
- 6.3 <u>Inhibit Film Drive</u> Ensure (*Film Tension Push-button*) is extinguished. The compliance arms are in the film lacing/unlacing position, film is NOT tensioned.
- 6.4 Remove Film from Vision Gate.
- 6.5 Invoke Detector Calibration.) Press (Auto Alignment Menu). This takes a few minutes; progress is shown on the display. With the Oliver option it is important to note one special procedure during the calibration. At about the 50% point in the detector calibration the local panel display will prompt "Please insert calibration card". A white card with high reflectance should be placed between the Relay Lens and the Oliver main block, with the highly reflective surface facing towards the film gate, as shown at * in Figure 105. Ensure the card covers the entire Oliver block aperture. Detector calibration should then be continued. The card should be left in place until the local panel display prompts for its removal "Please remove calibration card". This situation will NOT occur if Oliver is not fitted. Detector calibration should then be completed

Issue 1 Page 116 of 137

- 6.6 <u>Automatic Alignment</u>
- 6.7 <u>Check Gate Focus</u> Ensure the gate is correctly focused.
- 6.8 <u>Inhibit Film Drive</u> Ensure (*Film Tension Push-button*) is extinguished. The compliance arms are in the film lacing/unlacing position, film is NOT tensioned.
- 6.9 Remove Film from Vision Gate.
- 6.10 <u>Automatic Alignment</u> Press (Auto Alignment Menu) to invoke automatic alignment.. Alignment takes approximately 1.5 minutes; progress is shown on the display.
- 6.11 Recommended Alignment Beam Currents

As a general guide use an alignment beam current of 300µA with all film types...

6.12 Further guidance on Beam Current settings

A beam current of 300uA should be used for all film materials. A beam current of 150uA, used to potentially extend the CRT life, will reduce the performance of the scanner.

Alignment Failure

Alignment failure may result from incorrect PEC trip levels. To calibrate the PECs (detectors) see section 6.1 to 6.5, Detector Calibration

7 Running Film

- 7.1 <u>Lace Film and Focus Gate</u> See Procedure 4 or 5 if necessary.
- 7.2 Select Operating Beam Current Press C (Top Level Menu) to toggle between 150uA and 300uA as the operating beam current-ITOP LEVEL MENU C I.
- 7.3 Select Audio Source³ Press (Top Level Menu) to call-up the Audio Menu. **ITOP LEVEL MENU**. Select the required options from this menu.
- 7.4 Check Output Run the film, check framing, audio and video levels and adjust as necessary.
- <u>7.5</u> <u>Cue Telecine</u> Reverse run the film to the required starting point.
- 7.6 Reset Counter Press (Top Level Menu) to reset the counter. **ITOP LEVEL MENU** [1].
- 7.7 Run Film.

8 Powering-Down



Ensure that film tension is switched OFF (film tension push-button extinguished) BEFORE touching any part of the film transport mechanism.

- 8.1 Rewind Film Run film back onto the feed core. If auto stop is **ON** (*Transport Configuration Menu*) the film transport system will automatically shut down when the end of the reel is neared. To run film off select shuttle again.
- 8.2 <u>Check Film Transport</u> Ensure film transport system has stopped.

Issue 1 Page 117 of 137

³ If audio option fitted

User Handbook

- 8.3 Open Film Transport Door.
- <u>Inhibit Film Drive</u> Ensure that film tension is switched OFF (film tension push-button extinguished).




Film should NOT be left laced and hence tensioned while the Telecine is out of operation.

- 8.5 Remove Film Core.
- 8.6 Close Film Transport Door.
- 8.7 Switch Off EHT and CRT Heater Press CRT ON. This turns OFF both the EHT and the CRT heater.




The Telecine must be shut down as described below BEFORE the power is switched off. Failure to observe this procedure may corrupt the internal hard drive and delay the next switch on sequence.


8.8 Shutdown Telecine – Press and hold (Top Level Menu) to display the Status Page (Action 1).



With a still held press and hold and simultaneously (marked SHUTDOWN) to display the Shutdown Page (Action 2).



Press **9** (Shutdown Page) to confirm shutdown (Action 3).



Issue 1 Page 118 of 137

When complete the display indicates that the machine can now be switched off. Failure to correctly shut down the machine will incur a delay on next switch-on, as data on the hard drive needs to be checked for possible corruption.

8.9 <u>Switch Off Power</u> - Move power switch down into the **O** position to switch power OFF.

9 Invoking a Test Pattern

C-REALITY provides a selection of test patterns. These are available on the *Test Pattern Menu* that is shown in Figures 39-42.

- 9.1 Select the Test Pattern Menu Press (Engineering Menu #2) [TOP LEVEL MENU] > ENGINEERING MENU #1 | > ENGINEERING MENU #2 | > TEST PATTERN MENU].
- 9.2 Select Test Pattern Press **f** to **1** as required. **C** can be used to alter the orientation of the pattern.

10 Installing System Software (for the first time)


- 10.1 Switch Power ON Switch on the mains supply to the Telecine and then move the power switch up into the position to switch power ON. The switch is located at the front of the machine on the lower left-hand side. The power must be on for the CD drive tray to operate.
- 10.2 Insert CDROM Disc Open the Local Control Panel and insert the CDROM disc (System Software) into the LOWER drive. Ensure that the supplied floppy disk is always in the UPPER drive as this disk includes the Telecine configuration files. The floppy drive allows the firmware and machine configuration to be updated. Please refer to Cintel service department for further details.
- 10.3 Auto-Boot Telecine Switch power off and then on again to auto-boot the Telecine. Auto-booting takes approximately four minutes. **During this period do NOT perform any operations.** Refer to *Procedure 1* for further details.

Issue 1 Page 119 of 137

11 Setting the Best Primary Colour Correction at the Local Control Panel

- 11.1 Set Colour Defaults Press © (Engineering Menu #1) to set all colour controls to their default settings. It may be beneficial to save this as a base memory or note on the remote control desk for each film type. ITOP LEVEL MENU (#3 > ENGINEERING MENU #1 ©1.
- 11.2 Set APD Levels Setting the APD levels maximise signal-to-noise ratio and dynamic performance. These adjustments should be made from the local control panel to ensure that the Telecine's pre-set optimum APD levels are selected as a starting position for further adjustment and NOT any setting that may be pre-programmed in the control desk. These adjustments are essential in order to achieve the best performance from your Telecine.
 - (i) *Initial Adjustment* Press (Top Level Menu) to cycle through the options available on the display, NEG (Negative), POS (Positive) and IP (Inter-Positive). Selecting the film type automatically sets optimum APD levels for Kodak TAF: Positive, Inter-Positive or Negative Vision. ITOP LEVEL MENU (Inter-Positive).
 - (ii) Fine Adjustment Ensure that representative film* is in the gate. Press on the local control panel to select the PEC Control Menu. The following adjustments are made while viewing a waveform monitor
 - (a) For Positive and Inter-Positive film adjust (3) (PEC BLUE) to achieve the maximum level without clipping and then adjust (2) (PEC GREEN) and (1) (PEC RED) for balance.
 - (b) For Negative film, adjustments are made while **observing the black levels of the video signals.** Adjust (a) (PEC BLUE) to achieve the maximum level without clipping and then adjust (a) (PEC GREEN) and (b) (PEC RED) for balance. If desired increase pre-gamma lift (b) (Top Level Menu) and gain (c) to improve clip visibility. Reset these controls after APD adjustment is complete.
- * The film density should include a minimum density likely to be encountered in real transfer situations.
- 11.3 Set Film Masking Set the required masking either from the local control panel (on the Log Masking Menu) or the remote control desk. Masking can be selected independently of the film type to compensate for unwanted absorption and the inter-image effects of the dyes within the given film stock. The Log Masking Menu is selected on the local control panel by pressing (Engineering Menu #2). [Top Level Menu #3] > Engineering Menu #4 | Sengineering Menu *4 | Sengineering Menu *
- 11.4 Make Pre-Gamma Adjustments Adjust pre-gamma lift and gain (**Pre-only Mode**) either from the local control panel or the remote control desk minimal adjustments should be required to set and balance, black and white levels very accurate colour balance is not a pre-requisite at this point. Due to the extended dynamic range of the APD's it is not necessary for blacks and whites to be adjusted near to clip. Allow approximately 15-20% headroom for black and white levels as shown in the figure below to allow room to stretch blacks and whites when making post-gamma adjustments (**Normal Mode**).

Issue 1 Page 120 of 137



Master pre-gamma lift and gain adjustments can be made on the Top Level Menu on the local control panel: press (Top Level Menu) if required to select pre-gamma and then adjust and differential adjustments can be made from the PCC Control Menu: press (Engineering Menu #2) to select the PCC Control Menu. Refer to Figures 52-56 for further details. Top Level Menu #2 > Engineering Menu #1 > Engineering Menu #2 > PCC Control Menu.

11.5 <u>Make Post-Gamma Adjustments</u> – Adjust post-gamma lift and gain (**Normal Mode**). These adjustments can also be performed on the local control panel. The headroom allowed when making the pre-gamma adjustments allows plenty of room to stretch blacks and whites without going into clip.

Issue 1 Page 121 of 137

12 Setting Remote Controller Base memories and Defaults

This selection assumes some familiarity with Telecine controllers and terminology used for C-REALITY colour channel

Figures

Negative	Setup
----------	-------

Figure 1a Da Vinci PCC level Display	Figure 1b Pandora PCC level Display	
Figure 2 a Da Vinci Gains & Lift for PEC setup	Figure 2b Pandora Gains & Lift for PEC setup	Figure 2c Typical waveform prior to PEC adjustment
Figure 3 PEC gain in Negative in clip		
Figure 4 PEC gain in Negative best setup		
Figure 5a Da Vinci typical PCC levels in NEG	Figure 5b Pandora typical PCC levels in NEG	Figure 5c Typical Negative balanced waveform

Positive Setup

Figure 6a Da Vinci PCC level Display	Figure 6b Pandora PCC level Display	
Figure 7 a Da Vinci Gains & Lift for PEC setup	Figure 7b Pandora Gains & Lift for PEC setup	Figure 7c Typical waveform prior to PEC adjustment
Figure 8 PEC gain in Positive in clip		
Figure 9 PEC gain in Positive best setup		
Figure 10a Da Vinci typical PCC levels in POS	Figure 10b Pandora typical PCC levels in POS	Figure 10c Typical Positive balanced waveform

Inter-Positive Setup

Figure 11a Da Vinci PCC level Display	Figure 11b Pandora PCC level Display	
Figure 12a Da Vinci Gains & Lift for PEC setup	Figure 12b Pandora Gains & Lift for PEC setup	Figure 12c Typical waveform prior to PEC adjustment
Figure 13 PEC gain in Inter-Positive in clip		
Figure 14 PEC gain in Inter-Positive best setup		
Figure 15a Da Vinci typical PCC levels in IP	Figure 15b Pandora typical PCC levels in IP	Figure 15c Typical Inter-Positive balanced waveform

12.1 C-REALITY utilises a unique approach to primary colour correction, enabling a large dynamic range of control and therefore the ability to deal with even the most demanding of film.

To achieve results that make use of the superior benefits of C-REALITY it is important to ensure that your controller, da Vinci, or Pogle is pre-set to optimised defaults. These can be stored in Base memories (da Vinci), or Notes (Pogle)

Initial optimal adjustments ensure that the very best pictures are maintained in all respects and especially in terms of signal to noise performance and dynamic range. The important settings here are the PEC/APD controls.

While Cintel ensure that the scanner is in a near optimised mode on power up and under local control, switching to remote control, by necessity, will overwrite any locally stored settings. It is therefore necessary to establish these default settings within the remote controller memory.

The following describes C-REALITY and assumes that there are no base memories or notes set within the external controllers and that an auto alignment has been carried out – for best results 300uA beam current should be used. The basic concept for driving the APD pick up devices remains similar to PMTs used in earlier generations of Telecine such as Ursa or even MK3's. However the following includes specific references to functions available on C-REALITY.

Issue 1 Page 122 of 137


12.2 Stage 1. – NEGATIVE FILM TYPE

The Controller should be set in PRE Gamma mode only, with 'Extended PEC range' selected if applicable.

The Da Vinci GUI will indicate PRE Only mode by the 'greying out' of the post controls and a Red bar over the PRE control graphics. Figure 1a

The Pogle GUI indicates which mode is selected within the 'C-REALITY' window, and the tracker-balls turn Red. Figure 1b

Select Negative (Vision) log Masking (if desired). Toggle film type to Negative mode with the scene to be transferred already in the film gate. (TAF in this example)






Fig. 1a – Da Vinci Colour Bar Display (PRE ONLY mode)

Fig. 1b – Pogle C-REALITY PCC window (PRE ONLY mode)

Turn the master PRE Gain control up <u>significantly</u> and alter the master PRE Lift control such that the black level and black clip point can be seen easily on a waveform monitor (At this point all signals will be severely white clipped!). N.B. In negative, you will initially probably only see a signal in the Red Channel. See fig. 2a, 2b & 2c

Issue 1 Page 123 of 137



Fig 2a – Typical 'expanded' control values (Da Vinci)



Fig. 2b – Typical 'expanded' control values (Pandora)





Fig. 2c – Only red visible, all signals severely white clipped!

Issue 1 Page 124 of 137

12.3 Stage 2. – NEGATIVE FILM TYPE

Adjust all the PEC/APD controls such that the signals head towards video black i.e. you appear to be turning the signal levels <u>down</u>. Continue to turn the signals down until it is clear that the video is becoming black clipped. N.B. At this stage we are ONLY interested in the Blacks of the signals. See figure 3






Fig. 3 – R, G & B black levels clearly in clip.

Fig. 4 – PEC levels set correctly with headroom

If you do not see something similar to that shown in figure 3 above it may be that you need to turn the PRE lift controls a little higher or stretch the signals further with gamma or gain (N.B. Gamma cannot be altered on Pogle whilst in Pre gamma mode).

12.4 Stage 3. – NEGATIVE FILM TYPE

Now you have established where the detector clip points lie. N.B. operating in this area will result in some loss of picture information, it is now necessary to turn the signals up until the clip point is cleared and some head room allowed for as seen in figure 4.

THIS IS <u>THE OPTIMUM</u> SETTING FOR YOUR PEC's, THEY SHOULD NOT BE RE-ADJUSTED for the rest of this procedure. Usually this setting will be sufficiently accurate to cater for the rest of a roll but if significant exposure or stock changes occur, it should be re-checked. See Figure 4.

Issue 1 Page 125 of 137

12.5 Stage 4. – NEGATIVE FILM TYPE

The PRE Lift, Gain, and Gamma controls can now be returned to more usual levels such that the blacks and whites are unclipped and balanced. See Fig. 5a, 5b & c.



Fig. 5a – Typical Da Vinci Settings for PRE Gammas



Fig. 5b – Typical Pogle settings for PRE Gammas




Fig. 5c – Balanced RGB – Vision TAF (no Mask)

Issue 1 Page 126 of 137

The main purpose of the PRE Gamma correction is to present a balanced signal to the POST Gamma corrector, giving better luminance tracking of controls. You can now switch into POST Gamma mode where creativity can take over from Technical set up.

Cintel recommend that a Base memory or Note is created using the method described above for the latest Kodak Telecine Analysis Film (TAF).

12.6 Stage 1. – POSITIVE FILM TYPE

The Da Vinci GUI will indicate PRE Only mode by the 'greying out' of the post controls and a Red bar over the PRE control graphics. Figure 6a The Pogle GUI indicates which mode is selected within the 'C-REALITY' window, and the tracker-balls turn Red. Figure 6b Select Relevant log Masking (if desired). Toggle film type to Positive mode with the scene to be transferred already in the film gate.



Fig. 6a – Da Vinci Colour Bar Display (PRE ONLY mode)




Fig. 6b – Pogle C-REALITY PCC window (PRE ONLY mode)

Issue 1 Page 127 of 137

Turn the master PRE Gain control down significantly such that the white level can be seen easily on a waveform. See fig. 7



CReality 19 X 50% Rotate 0 Focus 50% Z 50% X Aspect 50 % Pre gamma Anam Y Aspect 50 % ☐ XFIIp ☐ YFIIp Lift + Gain Lift + Gain 0 Pre-Gamma Pre Only 0 0 Print Mask None Colour Test Freeze 50% Ext1 8dB On Ext2 8dB Off Audio None Meter Both Dolby SR Filter Flat Speaker Mono Mono Digital Off

Fig. 7b – Typical Da Vinci Settings for PEC set

Fig. 7c – Typical Pogle settings for PEC set.





Fig. 7a – Typical view with PRE gain turned down

Issue 1 Page 128 of 137

12.7 Stage 2. – POSITIVE FILM TYPE

Adjust the RG & B PEC/APD controls such that the signals head towards white i.e. you will appear to be turning the signal level <u>UP</u>. Continue to turn the signals UP until it is clear that the video is becoming white clipped. N.B. At this stage we are ONLY interested in the Whites of the signal. See figure 8






Fig. 8 – R, G & B white levels clearly in clip.

Fig. 9 – PEC levels set correctly with headroom

If you do not see something similar to that shown in figure 8 above it may be that you need to turn the PRE Gain controls further down and readjust your PEC controls.

12.8 Stage 3. – POSITIVE FILM TYPE

Now you have established where the detector clip point lies. N.B. operating in this area will result in some loss of picture information, it is now necessary to turn the signals down until the clip point is cleared and some head room allowed for as in figure 9.

THIS IS <u>THE OPTIMUM</u> SETTING FOR YOUR PEC's, THEY SHOULD NOT BE RE-ADJUSTED for the rest of this procedure. Usually this setting will be sufficiently accurate to cater for the rest of a roll but if significant exposure changes occur, it should be re-checked. See Figure 9.

Issue 1 Page 129 of 137

12.9 Stage 4. – POSITIVE FILM TYPE

The PRE Lift, Gain, and Gamma controls can now be returned to more usual levels such that the blacks and whites are unclipped and balanced. See Fig. 10a, 10b & 10c






Fig. 10a – Typical Da Vinci settings for PRE Gammas

Fig. 10b Typical Pandora settings for PRE Gammas




Fig. 10c – Balanced RGB – Positive TAF (no Mask)

Issue 1 Page 130 of 137

12.10 Stage 5. – POSITIVE FILM TYPE

The PRE Gain and Lift controls can now be re adjusted for a 'Flat' grade – i.e. Balanced, unclipped Blacks and Whites. You can now switch into POST Gamma mode where creativity can take over from Technical set up!

Cintel recommend that a Base memory is created using the method described above and the latest Kodak Telecine Analysis Film (TAF).

12.11 Stage 1. – INTER-POSITIVE FILM TYPE

The Da Vinci GUI will indicate PRE Only mode by the 'greying out' of the post controls and a Red bar over the PRE control graphics. Figure 6a The Pogle GUI indicates which mode is selected within the 'C-REALITY' window, and the tracker-balls turn Red. Figure 6b Select Relevant log Masking (if desired). Toggle film type to Positive mode with the scene to be transferred already in the film gate.








Fig. 11b – Pogle C-REALITY PCC window (PRE ONLY mode)

Turn the master PRE Gain control down significantly such that the white level can be seen easily on a waveform. See fig. 12a, 12b &12c.

Issue 1 Page 131 of 137



X 50% Rotate 0 0 Y 50% Focus 50% Z 50% X Aspect 50% 0 Pre gamma 0 Anam Y Aspect 50 % XFlip | YFlip Sat Contour Lift + Gain Lift + Gain 0 Pre Only Pre-Gamma 0 Mask None InterPos 0 Colour Test Freeze 50% Ext1 8dB On Ext2 8dB Off Audio None Meter Both Dolby SR Filter Flat Digital Off Mono Speaker Mono

Fig. 12a – Typical Da Vinci Settings for PEC set

Fig. 12b – Typical Pandora Settings for PEC set





Fig. 12c – Typical view with PRE gain turned down

Issue 1 Page 132 of 137

12.12 Stage 2. – INTER-POSITIVE FILM TYPE

Adjust the RG & B PEC/APD controls such that the signals head towards white i.e. you appear to be turning the signal levels <u>UP</u>. Continue to turn the signals UP until it is clear that the video is becoming white clipped. N.B. At this stage we are ONLY interested in the whites of the signal. See fig. 13






Fig. 13 – R,G & B white levels clearly in clip.

Fig. 14 – PEC levels set correctly with headroom

If you do not see something similar to that shown in the figure above it may be that you need to turn the PRE Gain controls further down and readjust your PEC controls.

12.13 Stage 3. – INTER-POSITIVE FILM TYPE

Now you have established where the detector clip point lies. N.B. operating in this area will result in some loss of picture information, it is now necessary to turn the signals Down until the clip point is cleared and some head room allowed for.

THIS IS <u>THE OPTIMUM SETTING</u> FOR YOUR PEC's, THEY SHOULD NOT BE RE-ADJUSTED for the rest of this procedure. Usually this setting will be sufficiently accurate to cater for the rest of a roll but if significant exposure changes occur, it should be re-checked. See Figure 14.

12.14 Stage 4. – INTER-POSITIVE FILM TYPE

The PRE Lift, Gain, and Gamma controls can now be returned to more usual levels such that the blacks and whites are unclipped and balanced. See Fig. 15a, 15b & 15c

Issue 1 Page 133 of 137



Fig. 15a – Typical Da Vinci settings for PRE Gammas





Fig. 15b Typical Da Vinci settings for PRE Gammas



 $Fig.\ 15c-Balanced\ RGB-Inter-Positive\ TAF\ (no\ Mask)$

Issue 1 Page 134 of 137

12.15 Stage 5. – INTER-POSITIVE FILM TYPE

The PRE Gain and Lift controls can now be re adjusted for a 'Flat' grade – i.e. Balanced, unclipped Blacks and Whites. For C-REALITY users you can now switch into POST Gamma mode where creativity can take over from Technical set up!

Cintel recommend that a Base memory is created using the method described above and the latest Kodak Telecine Analysis Film (TAF).

13 OTHER FUNCTIONALITY

- The user,may at this time, also wish to set default scan sizes and shapes. Bear in mind that when the C-REALITY scanner is correctly setup all scan sizes and shapes default to standards set by the film industry. Modifying these values for default storage in controllers will result in non standard scan areas being appied to the image.
- For operation procedures of the optional Oliver and Grace please refer to the suppliment handbooks for these products.
- 13.3 For further descriptions of C-REALITY functions please refer to C-REALITY Appendix A.

Issue 1 Page 135 of 137

Chapter 5

Appendix A.... An explanation of some of the C-REALITY functions

Pre Gamma and Post Gamma Control.

C-REALITY includes a method of Primary colour correction that can always be optimised regardless of film density ranges. Historically Film Scanners and Telecine colour correctors have had their input colour levels defined by detector adjustment and the film's density.

Where the film exposure is technically accurate such systems provide good results. However these results rely on a specific film density range representing the full image density range. While these densities can be accommodated differently between film types; negative, intermediate and print, it is not normally possible to accommodate variable ranges within each film type.

With traditional systems where the "White point" and "Black point" of the image may vary in density, either due to a non technically perfect exposure, or for artistic effect, or for a non standard film stock, the final image blacks and whites may not correspond with the expected densities. This will also mean that intermediate densities may be misrepresented.

In such cases the White Level and Black level pivot points of the colour correction will be incorrect. If the Gamma is adjusted it will also move the black and white points rather than just the intermediate values.

C-REALITY overcomes these limitations by providing effectively two sets of Primary colour correction. The first corrector can be adjusted to ensure that regardless of film densities ranges a suitable White Point and Black Point can be presented to the Gamma correction and subsequent colour correctors such that these points are the genuine pivot points for the Lift Gamma and Gain of the second stage.

The first colour corrector is called, logically, Pre-Gamma while the second corrector is called Post Gamma.

For all operations it is best to set the Pecs such that the signal is just out of clip for the thinnest film densities, Black for Negative and White for Inter Pos and Print. Theoretically only three settings are required, one for each film type.

Now as different rolls of film or different shots are graded the pre gamma controls can be set to get the best range from the images. In the real world the following are recommended. For negative operation set the pre-gamma controls such that a full density range scene occupies the entire signal range. For IP and print set the Pre-gamma controls such that the image signal occupies the mid 75% of the entire range.

From this point on most control will only require Post Gamma operation. However if a scene is very flat it can be advantageous to re visit the pre-gamma controls to "boost" the range before the gamma control.

The Pre & Post gamma controls can be experimented with for other settings to obtain unique looks. However remember to reset to your normal values before grading a new job as it is possible to have extreme pre-gamma settings that will cause strange post gamma control.

Note. Clipping the blacks or whites in pre gamma mode will not necessarily clip the image blacks and whites in Post Gamma mode.

For more details see the main user manual Procedures 11 and 12.

Issue 1 Page 1 of 8

PCC Gamma & Knee Functions



Normal Gamma
Stretch to lighten
Midtones and
Lowlights





S Gamma.
Highlights and
Lowlights crushed
Mid Tones stretched



Knee on S Gamma moved towards Lowlight Highlights Crushed. Lowlights stretched Blacks crushed

Issue 1 Page 2 of 8

PCC, S Gamma, HighLight &LowLight modes



Inverted S Gamma
Mid Tones crushed
Highlights and
Lowlights stretched





Highlight ModeHighlights
Compressed



Lowlight ModeLowlights
Compressed

Issue 1 Page 3 of 8

CVIP Vector Selection, Isolation and Effect adjustment (Note these images will only show correctly if displayed or printed in colour)







Vector HSL selected using Highlight Mode



Effect Hue adjustment.











Effect Hue, Saturation and Luminance adjustment Additional Vectors selected and adjusted

Issue 1 Page 4 of 8 C-REALITY
Appendix A


SCAN EFFECTS



X Skew
Vertical Edges all tilted same amount



X TiltSize change Left to Right, correct Horizontal perspective






Y Tilt
Size change Top to Bottom, correct Vertical perspective

Issue 1 Page 5 of 8

FOCUS EFFECTS








Fully Focussed Slight Defocus Mass Defocus


Issue 1 Page 6 of 8


SCAN ALIGN




Issue 1 Page 7 of 8

ASTIG







ad Bad Good, Readjust Focus

Issue 1 Page 8 of 8